



**Heckert Solar**  
Die Energiekompetenz

# Installation and operating manual

## PV-Modul NeMo 3.0 120 M



**Standard 15  
years product  
warranty**



**Produced with  
green energy**



**Made in Germany**

## **Installation and operating manual**

This operating manual is addressed to suppliers, installers and operators of PV systems with monocrystalline high-performance solar modules manufactured by Heckert Solar GmbH. It aims to ensure that the installed PV systems produces optimum yields through the entire running time. Non-compliance may render the warranty invalid. Please read the following instruction manual thoroughly.

Heckert Solar brand modules may only be installed by qualified specialist companies. Please observe the relevant standards and regulations for the installation and operation of photovoltaic plants, such as VDE requirements, DIN standards, the VDEW Guideline, the Technical Connection Conditions of the relevant network operators, as well as the rules of the employers' liability insurance associations on accident prevention, in particular IEC 62446 on operation and maintenance. Non-compliance may result in considerable personal injuries and material damage. The standards and laws applicable in Germany form the basis of the information contained in this installation and operating manual.

This installation manual should form part of the plant documentation, and should be available to the plant operator at any given time.

Heckert Solar reserves the right to amend the present document at any time without prior notice. Please use the most current copy. You can find this on our homepage under

<http://www.heckertsolar.com/de/downloads/partner-download-center/montage.html>.

This installation and operating manual is in accordance with IEC 61730-1:2016.

### Overview

1. Risks & safety precautions
2. General information on PV plants
3. Delivery & handling of the modules
4. Information on the module
5. Module installation
6. Connecting the modules
7. Returns & recycling
8. Product and service warranty
9. Exclusion of liability

### 1. Risks & safety precautions

Solar modules generate electricity as soon as they are exposed to light. It is hazardous to touch a module with a voltage of 30 volts or more. Each serial or parallel connection of modules increases the voltage or current. By connecting more than two solar modules in series, hazardous voltages may occur!



#### **Danger of death due to electric shock!**

Although touch protection is provided in the form of the fully insulated plug contacts, please ensure that

- no electrically conductive parts are inserted into the plugs or sockets when handling the solar modules!
- Solar modules and cables are not installed with moisturized male and female connectors!
- all works on the cables are undertaken with extreme caution!
- high contact voltages may still be present inside the inverter even when the unit is switched off!
- as a rule, caution is exercised when performing any work on the inverter and cables!

Heckert Solar brand modules correspond with Class II.



#### **Risk of death by electric arc!**

A deadly electric arc can result when opening a closed section (e.g. when separating the DC cable from the inverter under load):

- Never separate the solar generator from the inverter if the latter is connected to the grid!

### **Work on the roof**

Please observe the applicable accident prevention regulations. Do not carry out installation work when there are strong winds. Secure yourself and other persons from falling down. Prevent objects from potentially falling down. Secure the work area so that no other persons can be injured.

## 2. General information on PV plants

### **Orientation**

The solar module achieves the highest yield when oriented to the south (towards the North when in the southern hemisphere). The optimum angle of inclination outside the tropics can be estimated using the following equation:

Angle of inclination = latitude of the installation site minus 20.

Deviations from the optimum orientation and inclination of the modules lead to a reduction in yield.

Angle of inclination >75° may lead to regional restrictions.

### **Location**

The area planned for the installation should be as free as possible from shade of any kind (houses, trees, branches, chimneys, dormers, antennas, satellite dishes, cables, etc.), because shade can significantly reduce the efficiency of the solar modules. Even partial shading will lead to a significant reduction in yield. A module is considered "shade-free" when the entire surface is shade-free all year round and, even on the most unfavourable days of the year when the sun is low, receives unobstructed sunlight for several hours.

### **Rear ventilation**

The output of solar modules decreases considerably as the modules heat up. Rear ventilation avoids yield-impairing heat accumulation. The so-called "chimney effect" (draught behind the modules) should not be impeded if possible (e.g. roof windows, collectors).

### **Cleaning/ Maintenance**

With a sufficient inclination of the modules (>15°), there is a self-cleaning effect for rain and snow. Cleaning the modules is generally unnecessary.

However, the soiling of the modules is strongly dependent on the surrounding environment and should be checked once a year. In case of heavy soiling, it is recommended that the modules be cleaned after cooling down (e.g. in the morning) using plenty of warm, de-mineralised water and a gentle cleaning device, as sharp-edged items might lead to scratches on the surface or to destruction of the anti-reflective (AR) coating. For modules with AR glass, clean, lint-free, microfibre cloths or paper towels should be used. Fatty or oily deposits can be removed with alcohol or alcohol-water mixtures. You should also refrain from using strong acids, alkalis, benzene-based cleaning agents or hot cleaning agents, as well as cleaning agents containing silicone oil, fluorides or wax, polishes, alkaline cleaning agents and cleaning agents with abrasive chemical products or high-pressure cleaners. Any methods, means or conditions which can exchange Na ions from the glass surface are unsuitable for cleaning glass. All abrasive cleaning agents and utensils are also unsuitable. Please note that too great differences in temperature can lead to tension in the glass, which may damage the module.



**Please make sure that the earthing is not interrupted or destroyed when carrying out cleaning and maintenance work!**

### 3. Delivery & handling of the modules

The goods must be checked immediately upon delivery to ensure completeness and integrity. Only damages which are noted on the driver's delivery receipt and are immediately communicated in written form to Heckert Solar can be recognised as transport damages.

In general, our brand modules are packed upright on a one-way pallet of up to 29 or max. 19 modules. Take care when unpacking, transporting and storing the modules. We recommend keeping the modules in their packaging until ready for installation. Always set the pallets on a reinforced level ground and do not stack them under any circumstances.

	Standard packaging	Picking packaging
<b>Number of modules/ pallets</b>	19-30	1-19
<b>External dimensions(WxLxH)</b>	1.1 m x 1.2 m x 1.94 m	1.1 m x 1.2 m x 1.94 m
<b>Weight of full pallet</b>	645 kg	420 kg
<b>Quantity per truck</b>	24 pallets * 30 modules = 720 St.	24 pallets * 19 modules = 456 St.



**The packaging is not film-wrapped and is therefore not resistant to rain!**



**Please be sure to observe the unpacking instructions on the packaging! Never remove the rear retaining strap from pallets with 29 modules!**




Figure 1: Standard packaging: Pallet with 29 modules




Figure 2: Picking packaging: Pallet with 19 modules or fewer



### Exercise caution when working with the modules!

- Carry the modules with both hands. Do not use the connection sockets or cables(s) as a handle. During the transport and installation, take care that no pressure or tension is exerted on connection sockets and cables.
- Protect the modules from any hard knocks! Do not set the modules down roughly on hard ground. Do not set the modules down on their corners. Do not place the modules on top of each other unprotected. Do not place any objects on the modules. **Never stand on the modules!** Do not allow the modules to fall or use hard or pointed objects on them.
- Special care must be taken to connect the modules in accordance with the instructions and should not be forced. Keep all electrical contacts clean and dry.
- A dry, well-ventilated room should be used to store the modules if necessary.
- For the system documentation, it is advisable to make a note of the serial number and address of the place of installation on the installation plan.
- Do not install any damaged modules.



### Please observe the specific instructions for handling solar modules with AR glass.

Compared with non-coated glass, the surface of AR glass has a similar resistance to mechanical or chemical influences and should be handled with a similar level of care. However, due to its special reflective properties, light soiling is more visible than on non-coated glass. In particular, fats and oils are already visible in small quantities and may influence transmission. In order to avoid hand prints, the modules should only be touched with clean gloves.

#### 4. Information on the module

##### **Certification and Performance Data**

For the performance data and instructions on certificates for our brand modules, please refer to the datasheets for the respective series.

##### **Use**

Please observe the following points in particular for the use of our brand modules:

- The installation or operation of the solar modules is permissible up to an altitude of max. 2000 m above sea level.
- The function of the modules is tested at an ambient temperature of -40 to +40°C. This area should be adhered to.
- The solar module is not saltwater-resistant (recommended distance from the sea: 500 m).
- The module must not be subjected to unusual chemical loads (e.g. emissions from manufacturing plants).
- Do not immerse the solar module in liquid.

- Do not use any lenses or mirrors to concentrate light (risk of overheating).
- Avoid damage to the module from using carbide or diamonds.
- Protect solar modules from overvoltage, e.g. voltage peaks from battery-charging devices, alternator generators etc. (Please ask your specialist retailer in case of any doubt).
- If solar modules are connected to energy-storage devices, the safety instructions of the respective manufacturer must be followed.
- Keep children away from solar modules.

In southern regions, a PV module can supply greater power and/or a higher voltage than stated for the standardised test conditions (standard test conditions). For this reason, in order to define the rated voltage values of components, rated current values of wires, the size of fuses that are to be connected at the output of PV modules, the  $I_{sc}$  and  $V_{oc}$  values listed on the module should be multiplied by 1.25. The highest rated value for overcurrent protection (reverse current resistance) is 20 A.

## 5. Module installation

### **General instructions on module installation**

All modules can be fitted both horizontally and vertically independent of the connector sockets.

The modules must not be subject to stress during installation. The modules cannot be used as a rigid linking or fixing element.

Please be advised that the holes in the frame and in the corners must remain free in order to allow condensed water to flow out.

### **Load on the modules**

The load capacity of standard solar modules is independent of the installation situation and the system used. Please observe the installation situations in the following table and the resulting maximum load capacity of the modules.

The values shown (Figure 3) correspond to the design load in accordance with IEC 61215: 2016. The cyclical load test is carried out according to the standard of a 1.5 times higher test load.

### **Default situation for continuous mounting rails**

Please note that the module can bend under high loads and can strike the mounting rails. Ensure that the mounting rail displays a sufficient stability and the fixing points are set frequently and correspondingly to prevent the mounting rail from bending. (Tested with Heckert Solar rails and a support spacing of max. 1m)

Ensure that the maximum mechanical load is not exceeded, in particular while also taking into account the site-dependent loads, e.g. wind and snow (DIN 1055-4/5).

Do not use any fixing material that might damage the module e.g. due to pointed, sharp or uneven structures. Please note that the module bends under load and can strike the supporting surface/ mounting rails. Ensure that the connector sockets and cables, when necessary, are not damaged or exert pressure on the cells.

The total snow load on the ground  $s_k$  in kN/m results from the respective snow load zone, the building site and the ground height above sea level. The total wind load for the project site must be determined from the wind zone map, which takes into account the site situation as well as wind zones. For buildings up to a height of 25 m, the total wind load may be determined through a simplified procedure. Independent of building heights, the wind load is specified as velocity pressure  $q$  in kN/m<sup>2</sup>.




					
2 continuous rails under module 4 fixing points a = 280; b = 150		4 fixing points in the corners a = 10; b = 200		Positioned linearly on the long side	
Test load	Design load	Test load	Design load	Test load	Design load
Pressure 5400 Pa	Pressure 3600 Pa	Pressure 1950 Pa	Pressure 1300 Pa	Pressure 3600 Pa	Pressure 2400 Pa
Suction 2400 Pa	Suction 1600 Pa	Suction 1950 Pa	Suction 1300 Pa	Suction 2400 Pa	Suction 1600 Pa

Figure 3: Load capacity depending on the installation situation



**The maximum load capacity of the modules can only be achieved by clamping the specified area and complying with all conditions!**



**Please note that the planning and execution of the project is the sole responsibility of the installation company, and in some cases, it is necessary to prepare property statics!**

## Load

## restraints

To prevent the modules from slipping on sloped surfaces during installation and to facilitate installation, our module frames are fitted with holes for load restraints. Screws with hexagon socket head caps are fixed in these holes in the module frame. The screws are fastened with a washer and nut or using a self-locking nut. An M5x10 VA screw and the corresponding toothed washer and nut is recommended for the load restraints.

## 6. Connecting the modules

The Heckert Solar solar modules are equipped with Original MC4 connectors (Stäubli – MultiContact)



**Only connectors in accordance with DIN EN 62852 (VDE 0126-300) may be used. In addition, only connectors from the same manufacturer may be plugged together.**

Please note that only the proper tool may be used for the crimping of connectors.

Defective crimped connections may cause significant damage to the modules and could even cause the plant to burn down.

The modules are connected to the strings in series. This adds the voltage of the modules to the string. Please note that the permissible system voltage of 1000V may not be exceeded even at very low temperatures.





**Please note that it is imperative to avoid tensile force on the connection cables.**



**Please note that only the manufacturer's connectors may be connected. Even "compatible" connectors can loosen the connection and cause an electric arc. This is especially important to consider when using power optimizers!**



**Any change in the connector socket can lead to the warranty being rendered null and void, and therefore may only be carried out by trained and skilled personnel.**



**No damaged modules may be installed!**

Both external connector sockets are fitted with a cable (1150 mm in length) and connectors. The socket (+) is located on the right-hand side, and the plug on the left-hand side (-). (Figure 4) The connectors are each designed in such a way as not to create confusion.




Figure 4: Configuration of the connector sockets

The individual solar modules in a string can be interconnected effortlessly.



**Please ensure the correct connection of the plugs and sockets!**



Figure 5:

Connected MC4 modules

The string cables are connected to the MC4 connectors on the first or last module in the string.



The connectors comply with IEC 62852.

Please be sure to observe the requirements set out in DIN VDE 0298-3 for cable routing, in particular the smallest permissible bending radii (Figure 6;  $R > 5 \times \text{cable } \varnothing$ ) and the guidelines for cable fastening and routing.



Figure 6: Bending radii

- The connectors have a protection class of IP68 after connecting to the plug; the connector socket has a protection class of IP65. Both components are permanently protected against environmental influences.



Figure 7: Protection class

- Please be sure to observe the instructions and installation instructions of the respective manufacturer. See Annex. You can also find the MultiContact instructions on our homepage under (<http://www.heckertsolar.com/de/downloads/partner-download-center/montage.html>).

### Cable routing

Per string, 2 cables are required per string, that connect the solar generator to the inverter. Please use solar cables that comply with the standard EN 50618 class 5 and the respective requirements. The minimum cross-section is 4mm<sup>2</sup>. Cable losses should be < 1%. At greater distances, the cable cross-section must be adjusted accordingly. Please be sure to observe the requirements set out in DIN VDE 0298-3 for cable routing.

The strings (+ and - cables) are fed into the inverter and connected to the DC inputs. The module connectors are marked. To avoid conductor loops, the strings (+ and -) should be laid together.

When connecting the strings to the inverter, ensure that its polarity is correct. The + and - cables must not be interchanged. Using a multimeter/voltmeter, the polarity and voltage of the individual strings should be verified before connecting them to the inverter.

Only certified, suitable connectors are approved for the connection of the solar cables to the inverter. The installation or connection of the inverters should be carried out in accordance with the manufacturer's instructions.

The inverter manufacturer's instructions are binding.



**Pleasure ensure that there is no tension when routing the cables and that the plug and crimp are properly connected!**



**Depending on the module performance and inverter type, different length strings are possible. Make absolutely sure that the permissible system voltage cannot be achieved at full-load ( $V_{oc}$ ) and at low temperatures.**

### Parallel boarding of PV modules

When wiring our brand modules, it should be noted that string fuses (safety fuse 16 A) must be used for the parallel boarding of more than 2 strings.

The maximum reverse current load capacity is 20 A. Where more than two strings are connected in parallel, this may be exceeded in the case of a fault.

### Electrical installation

Connection of the inverter to the public electricity network must be carried out by an authorised specialised company.



**Even at low solar radiation, there is high DC voltage. Never touch unprotected + and - cables that are in operation!**

### Equipotential bonding

The requirements for the lightning and surge protection are dependent on the local conditions. Where there is already an external lightning protection system in place or planned for the building, the PV system must be integrated in the protection system against a direct lightning strike.

When using transformer-less inverters, due to the galvanic isolation, equipotential bonding may be required for reasons of personal safety. Country-specific laws shall apply.

The responsibility for a professional equipotential bonding of the module frame lies with the installing company. Country-specific standards must be adhered to.

A hole is drilled in the middle of the short sides of the module frame for equipotential bonding, and is marked with the corresponding symbol (Figure 8).

An M4 screw is required for equipotential bonding. The fixing must be carried out using a spring washer or toothed washer to ensure that the anodized layer is penetrated.




Figure 8: Equipotential bonding symbol and execution

### Fire prevention

The installation of on-roof systems can affect the fire safety of a building; improper installations can result in a hazard in case of fire. Please observe LBO Building Law requirements. In the event of on-roof systems, the Heckert Solar brand modules must be installed above a fire-resistant surface ("hard roofing" in accordance with DIN 4102-4). The

module is “non-explosion-proof operating equipment”. It may not be installed near highly-flammable gasses and vapours (e.g. petrol stations, gas containers or spraying systems). The module may not be installed near open flame or flammable materials.

The Heckert Solar modules were verified for their fire behaviour in accordance with IEC 61730-1:2004 und ISO 11525-2:2014. Our modules are considered to be flame retardant (Fire-resistance class C). Heckert Solar does not accept any warranty claims for inadequate supporting surfaces, in particular roof covering.

A clear labelling of the PV system and installation diagram, on the domestic junction box and the main building distribution board, are normative.

#### 7. Returns & recycling

Returns & recycling of solar modules are governed by the WEEE ElektroG2 Directive. Please observe country-specific regulations. Where applicable, notification may be required in the respective country.

EAR registration number DE42676826

#### 8. Product and service warranty

Information and terms for our product and service warranties can be found on our homepage under [www.heckert-solar.com](http://www.heckert-solar.com) .


#### 9. Exclusion of liability

These installation and operating instructions apply to general installations. All information is supplied without guarantee. Heckert Solar GmbH shall assume no liability for the usability and functionality of the system if there are deviations from the instructions contained in this user information. Given that neither compliance with this user information, nor the conditions, use and methods of installation, nor system operation, nor maintenance of the modules can be checked or monitored by Heckert Solar GmbH, the latter shall assume no liability for damage resulting from unintended use, incorrect installation, operation, use or maintenance.

Moreover, liability for patent infringements or infringements of other third-party rights resulting from the use of the modules is excluded unless liability is mandatory by law.

Our technical service department would be happy to answer any other questions you may have and can be reached at: +49(0)371/458568-0

Annex: Assembly instructions MC4 connector (Stäubli)



## Erforderliches Werkzeug

### (ill. 1)

Abisolierzange **PV-AZM...** inkl. eingebauten Abisolier-Messern sowie Sechskantschlüssel SW 2,5.

Leiterquerschnitt: 1,5 / 2,5 / 4 / 6mm<sup>2</sup>

Typ: PV-AZM-1.5/6

Bestell-Nr. **32.6029-156**

Leiterquerschnitt: 4 / 6 / 10 mm<sup>2</sup>

Typ: PV-AZM-4/10

Bestell-Nr. **32.6027-410**



### (ill. 2)

Crimpzange **PV-CZM...** inkl. Locator und eingebautem Crimpeinsatz.

Crimpbereich:

1.5/2.5/4 mm<sup>2</sup> (14/12 AWG)

Typ: **PV-CZM-18100**

Bestell-Nr. **32.6020-18100**

Crimpbereich:

2.5/4/6 mm<sup>2</sup> (12/10 AWG)

Typ: **PV-CZM-19100**

Bestell-Nr. **32.6020-19100**

Crimpbereich:

4/10 mm<sup>2</sup> (12 AWG)

Typ: **PV-CZM-20100**

Bestell-Nr. **32.6020-20100**



### (ill. 3)

**PV-MS** Montageschlüssel, 1 Set = 2 Stück

Bestell-Nr.: **32.6024**




(ill. 4)  
**PV-WZ-AD/GWD** Steckschlüssel  
zum Anziehen  
Bestell-Nr. **32.6006**



(ill. 5)  
**PV-SSE-AD4** Steckschlüssel zum  
kontern  
Bestell-Nr. **32.6026**




(ill. 6)  
**PV-PST** Prüfstift  
Bestell-Nr. **32.6028**



(ill. 7)  
SW15 Gabelschlüssel



(ill. 8)  
SW12 Drehmomentschlüssel



## Vorbereitung der Leitung

Anschlussleitungen mit einem Litzen-  
aufbau der Klassen 5 und 6 können  
angeschlossen werden.

### ⚠ Achtung:


Verwenden Sie keine blanken  
oder bereits oxydierten Leiter.  
Verzinnte Leiter sind vorteilhaft.  
Sämtliche Solarkabel von MC  
haben hochwertige, verzinnte  
Leiter.

### (ill. 9, Tab. 1)

Kontrollieren Sie die Masse A und b  
gemäss Illustration 9 und Tabelle 1.

Tab. 1

b: Kontrollmass b: Control dimension		Leitungsquerschnitt Conductor cross section	A: Ø-Bereich Leitung / A: Ø range of cable mm	
			3,0 - 6,0	5,5 - 9,0
mm	mm <sup>2</sup>	AWG	Typ / Type	
~ 3	1,5 - 2,5	14	PV-K...T4/...2,5I	PV-K...T4/...2,5II
~ 5	4 - 6	12 / 10	PV-K...T4/...6I	PV-K...T4/...6II
~ 7,2	10	-		PV-K...T4/...10II



### (ill. 10)

Leitung abisolieren.  
Entfernen Sie die Isolation des Kabels auf einer Länge von 6,0 bis 7,5 mm.

#### ⚠ Achtung:

Schneiden Sie beim Abisolieren keine Einzeldrähte ab!


#### i Hinweis:


zur Bedienung der Abisolierzange PV-AZM... sowie zum Auswechseln von Messersätzen entnehmen Sie bitte der Bedienungsanleitung MA267 auf [www.multi-contact.com](http://www.multi-contact.com)

## Crimpen

### (ill. 11)


Öffnen Sie den Klemmbügel (K) und halten Sie ihn fest. Legen Sie den Kontakt in den passenden Querschnittsbereich. Drehen Sie die Crimplaschen nach oben. Lassen Sie den Klemmbügel (K) los. Der Kontakt ist fixiert.





**(ill. 12)**

Drücken Sie die Zange leicht zusammen, bis die Crimplaschen sicher innerhalb der Crimp-Matritze liegen.



**(ill. 13)**

Führen Sie das abisolierte Kabel ein, bis die Isolation am Crimp-Einsatz anschlägt. Schliessen Sie die Crimpzange ganz.



**(ill. 14)**

Kontrollieren Sie die Vercrimpung visuell.

**i Hinweis:**  
zur Handhabung der Crimpzange entnehmen Sie bitte der Bedienungsanleitung MA251 auf [www.multi-contact.com](http://www.multi-contact.com)



## Montage-Prüfung




### (ill. 15)

Führen Sie den angecrimpten Kontakt von hinten in die Stecker- bzw. Buchsenisolation ein bis zum Einrasten. Prüfen Sie durch leichtes Ziehen an der Leitung, dass das Metallteil richtig eingerastet ist.



### (ill. 16)

Stecken Sie den Prüfstift mit der entsprechenden Seite in die Buchse bzw. in den Stecker bis zum Anschlag. Bei richtig montiertem Kontakt muss die weiße Markierung am Prüfstift noch sichtbar sein.



### (ill. 17)

Ziehen Sie die Leitungsverschraubung mit den Werkzeugen **PV-MS** handfest an

oder

ziehen Sie die Leitungsverschraubung mit den Werkzeugen **PV-WZ-AD/ GWD** und **PV-SSE-AD4** an.

### In beiden Fällen gilt:


Das Anzugsdrehmoment muss auf die konkret verwendeten Solarleitungen abgestimmt werden. Typische Werte liegen im Bereich von 2,5Nm bis 3Nm.


## Stecken und Trennen der Kabelkupplung ohne Sicherungshülse PV-SSH4

### Stecken

#### (ill. 18)

Stecken Sie die Kabelkupplung zusammen bis zum Einrasten. Kontrollieren Sie das korrekte Einrasten durch Ziehen an der Kabelkupplung.





## Trennen

### (ill. 19)

Zum Trennen der Kontakte drücken Sie die Einrastlaschen (X) entweder von Hand oder mit dem Werkzeug PV-MS zusammen und ziehen Sie die Kabelkupplung auseinander.

## Stecken und Trennen der Kabelkupplung mit Sicherungshülse PV-SSH4

## Stecken

### (ill. 20)

Stecken Sie die Kabelkupplung zusammen bis zum Einrasten. Kontrollieren Sie das korrekte Einrasten durch Ziehen an der Kabelkupplung.

## Trennen

Die Kabelkupplung kann nur noch mit dem Werkzeug PV-MS getrennt werden. Drücken Sie die Einrastlaschen (X) mit dem Werkzeug PV-MS zusammen und ziehen Sie die Kabelkupplung auseinander.